Technical Data Sheet

Pop-Up Valve Large



Note: Read and follow the Blastline Blast machine operations manual and provide proper training for all users of the device in order to achieve a safe and effective blasting operation.



Description


- Automatic pressure scaling pop-up valve.
- Allows for fast pressurization of blast pot.
- Durable reinforced rubber mushroom head.
- Stem approx 150 mm long and 21 mm external diameter.
- Very hard wearing and long lasting. Fits 50L & above blast machine.

Purpose

The blastline internal pop-up valve ensures fast pressurization of blastline blast machines. The automatic pressure scaling pop-up valves are fitted with reinforced metal guards, which makes them incredibly hard-wearing.

Safety

Prevent from causing excessive pressure inside the blast machine. A metering valve is placed on the bottom and pop-up valve on top. When excessive pressure is caused, it automatically releases some pressure and maintains the system at equilibrium.



Parts List

Item	Part no.	Description	Qty
1	PV-000001	Pop-up valve	1
2	PV-0000002	Plate	1
3	PV-000003	Tube	1
4	PV-000004	O ring	1